

QUIK-DRAW® OPERATING INSTRUCTIONS

TO REPOSITION THE SLIDER:

1. On a level surface, **apply** trailer parking brakes.
2. **Remove** manual stop bar (if applicable) and **move** it to desired position.
3. **Pull** QUIK-DRAW knob out to retract locking pins (never force or use tools on knob).
4. Gently **rock** trailer fore and aft to fully retract any bound pins.
5. **Move** trailer until slider is in desired position. **Trailer parking brakes must remain applied.**
6. **Push** QUIK-DRAW valve knob in to engage locking pins.
7. Visually **check** all locking pins for proper engagement — chamfered ends of locking pins must project through body rail at all four locations.
8. **Install** manual stop bar directly behind slider system.
9. Gently **rock** trailer fore and aft to check pin engagement.

For more details, refer to Hendrickson publication L738 *QUIK-DRAW Procedures*.

 **HENDRICKSON** Trailer Commercial
Vehicle Systems
866.RIDEAIR (743.3247)

www.hendrickson-intl.com



WARNING

DO NOT operate the vehicle without all slider pins completely through body rails



CAUTION

DO NOT operate the vehicle without air pressure in air springs



Warranty and important literature:

L583 *Comprehensive Warranty Statement*

L1074 *Slider Suspension Information*

Go to: www.hendrickson-intl.com/trailerlit