



⚠ CAUTION

Hendrickson has added a shear-type bolt and a second washer to the lower shock absorber connection. To apply the proper torque, the washers must be installed on both sides of the shock absorber and the shear-type bolt must be tightened until the bolt's Torx head shears off. Use an E20 Torx socket to tighten and shear the bolt. Torx head separation will occur between 210 - 235 ft. lbs. (285 - 318 N•m) of torque. Failure to follow these instructions could result in damage to the suspension and/or its components.

Trailer Suspension Systems
 2070 Industrial Place SE
 Canton, OH 44707-2600 USA
 800.455.0043
 330.489.0045
 Fax 800.696.4416

H HENDRICKSON

Trailer Suspension Systems
 250 Chrysler Drive, Unit #3
 Brampton, ON L6S 6B6 Canada
 905.789.1030
 Fax 905.789.1033