

# QUIK-DRAW® OPERATING INSTRUCTIONS

## TO REPOSITION THE SLIDER:

1. On a level surface, apply trailer parking brakes.
2. Remove manual stop bar (if applicable) and move it to desired position.
3. Pull QUIK-DRAW knob out to retract locking pins (never force or use tools on knob).
4. Gently rock trailer fore and aft to fully retract any bound pins.
5. Move trailer until slider is in desired position. Trailer parking brakes must remain applied.
6. Push QUIK-DRAW valve knob in to engage locking pins.
7. Visually check all locking pins for proper engagement — chamfered ends of locking pins must project through body rail at all four locations.
8. Install manual stop bar directly behind slider system.
9. Gently rock trailer fore and aft to check pin engagement.

For more details, refer to Hendrickson publication L738 *QUIK-DRAW Procedures*.

 **HENDRICKSON** Trailer Commercial  
Vehicle Systems  
866.RIDEAIR (743.3247)

[www.hendrickson-intl.com](http://www.hendrickson-intl.com)

## **WARNING**

**DO NOT** operate the vehicle without all slider pins completely through body rails

## **CAUTION**

**DO NOT** operate the vehicle without air pressure in air springs

**ZMD® Shockless suspension** equipped with **Zero Maintenance Damping®** components



**Warranty and important literature:**

**L583 *Comprehensive Warranty Statement***

**L1074 *Slider Suspension Information***

Go to: [www.hendrickson-intl.com/trailerlit](http://www.hendrickson-intl.com/trailerlit)