

LIT NO: L869 DATE: May 2004

## Items provided but not factory installed on all TIREMAAX<sup>™</sup> systems



## INSTALLATION MATERIALS AND SUPPLIES

The installer may be required to provide the following:

- Spindle plug driver and handle (unless the spindle plugs are already installed in the axle from the factory)
- Air lines and fittings
- Warning lamp and wire
- Optional hand-held programming device to set target tire pressure (if a target tire pressure other than the preset value is desired)
- Controller assembly mounting bolts
- A regulated air supply at or below the target tire pressure (to pressurize the system for leak checks)
- An air chuck with a ¼-inch push-to-connect fitting (conveniently attaches to the exhaust tube on the controller, used to pressurize the system for leak checks)

Refer to L818 for complete details





JorThe Road Ahead™

## Items factory installed on TIREMAAX<sup>™</sup> - prepped axles





Information contained in this literature was accurate at the time of publication. Product changes may have been made after the copyright date that are not reflected. Trailer Suspension Systems 2070 Industrial Place SE Canton, OH 44707-2600 USA

Trailer Suspension Systems 250 Chrysler Drive, Unit #3 Brampton, ON L6S 6B6 Canada 866.RIDEAIR (866.743.3247) 330.489.0045 Fax 800.696.4416

> 905.789.1030 Fax 905.789.1033

www.hendrickson-intl.com

The Boler Company. Copyright © 2004 All Rights Reserved