

## HASSEMBLY INSTRUCTIONS

# Transverse Torque Rods for U.S. and Canada

SUBJECT: Requirements and Guidelines LIT NO: 59310-004 DATE: December 2020 REVISION: G

## INTRODUCTION

This publication is intended to assist maintenance personnel with the installation, as-needed for aftermarket service replacement purposes, of the transverse torque rods for applicable Hendrickson truck suspensions operated in the U.S. and Canada. Transverse torque rods provide lateral support for Hendrickson suspensions. They also provide greater stability and roll stiffness as well as keep the axle centered laterally and help control axle walk-out on rear suspensions.

Refer to Hendrickson Literature Numbers 45745-148 and 45745-475 for additional information available online at www.hendrickson-intl.com

### **SAFETY PRECAUTIONS**

## **WARNING**

WARNING

TRANSVERSE TORQUE RODS ARE INCORPORATED FOR VEHICLE STABILITY. IF THESE COMPONENTS ARE DISCONNECTED OR ARE NONFUNCTIONAL THE VEHICLE SHOULD NOT BE OPERATED. FAILURE TO DO SO CAN RESULT IN ADVERSE VEHICLE HANDLING AND POSSIBLE TIRE CONTACT WITH THE FRAME, SEVERE PERSONAL INJURY, AND PREMATURE COMPONENT DAMAGE.

DO NOT MODIFY OR REWORK PARTS WITHOUT AUTHORIZATION FROM HENDRICKSON OR THE ORIGINAL EQUIPMENT MANUFACTURER. DO NOT SUBSTITUTE OR USE REPLACEMENT COMPONENTS NOT AUTHORIZED BY HENDRICKSON OR THE ORIGINAL EQUIPMENT MANUFACTURER. USE OF MODIFIED, REWORKED, SUBSTITUTE OR REPLACEMENT PARTS NOT AUTHORIZED BY HENDRICKSON MAY NOT MEET HENDRICKSON'S OR THE ORIGINAL VEHICLE MANUFACTURER'S SPECIFICATIONS, AND CAN RESULT IN FAILURE OF THE PART, ADVERSE VEHICLE HANDLING, POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE AND WILL VOID ANY APPLICABLE WARRANTIES. USE ONLY HENDRICKSON AUTHORIZED REPLACEMENT PARTS.

## TRANSVERSE TORQUE RODS

**Transverse torque rods are required** for vehicles equipped with the following Hendrickson rear suspensions:

#### **Air Suspensions**

#### Equalizing (Walking) Beam Suspensions

		1. 3. 37	
• AR2™	• PRIMAAX® EX • PRIMAAX	• HAULMAAX® EX	• HN®
COMFORT AIR®	• FIREMAAX <sup>®</sup> EX • FIREMAAX	• HAULMAAX	• HN FR
• HAS™ • HAS 40LH	• ROADMAAX®		
		•	1

**NOTE** Transverse torque rods **ARE NOT** allowed to be used in conjunction with Hendrickson walking beam suspensions equipped with bronze center bushings.





Grade 8 Bolts and

Hardened Washers

## 

WHEN TRANSVERSE TORQUE RODS ARE USED ON THOSE HENDRICKSON WALKING BEAM SUSPENSIONS, EQUIPPED WITH CENTER BUSHINGS, EACH EQUALIZING BEAM MUST USE A RUBBER CENTER BUSHING. EQUALIZING BEAMS THAT CONTAIN A BRONZE CENTER BUSHING MUST BE CONVERTED TO A RUBBER CENTER BUSHING PRIOR TO INSTALLING TRANSVERSE TORQUE RODS. FAILURE TO DO SO CAN CAUSE PREMATURE COMPONENT WEAR AND/OR ADVERSE VEHICLE HANDLING.

**Transverse Torque Rods are recommended** where it is necessary to restrict the lateral movement of the axles to prevent interference of the tires, brakes, axle housings, etc. with the frame, body, or suspension components. The proper clearance is determined by the vehicle manufacturer prior to vehicle assembly.

**Transverse torque rods are also required** for vehicles equipped with the following Hendrickson equalizing (walking) beam suspensions equipped with rubber center bushings:

Suspension	Capacity	Less than 60"	60" and longer	
	34K	*		
R • RS • RT • RTE	40K	*	-	
	44K – 52K	Required	Required	
R • RS • RT	65K	*		
RT	70K	Required		
ULTIMAAX	46K – 63K	Req	uired	
Suspension	Capacity	64" and Less Longer than 64		
R • RS	85K – 120K	*	Required	


#### EQUALIZING BEAM LENGTH

★ Transverse torque rods ARE REQUIRED in all refuse, mining, and logging applications, and available for vehicles in other applications also.

Transverse Torque Rod

Axle Bracket

## Installation | Recommended Guidelines




2

34" Minimum Clearance

through articulation

(both axles)

- With the vehicle at loaded ride height, the transverse torque rod horizontal centerline has an angle of 90° ± 2.5° to the frame, see Figure 1.
- The transverse torque rod frame brackets are mounted to the frame and located as close as possible to either the bottom frame flange (preferably) or top frame flange, see Figure 1.
- Frame backup plates are required (may be supplied by the vehicle manufacturer) with transverse torque rod frame brackets, see Figure 1.
- Transverse torque rods should be positioned as low as possible to the horizontal center-line of the axle, but high enough as not to interfere with axle components during articulation.




- Install transverse torque rods perpendicular to the frame rails  $(90^\circ \pm 2.5^\circ)$ , see Figure 2.
- A vehicle equipped with transverse torque rods may experience some reduction in suspension articulation or increased lateral stiffness and resistance to turning, especially with radial ply tires.

## TRANSVERSE TORQUE ROD AXLE BRACKETS

Hendrickson does not set the guidelines with regard to transverse torque rod axle bracket heights or footprints, due to the many variations of axle combinations, frame widths, and suspension ride heights. Refer to the vehicle manufacturer for component specifications.

Hendrickson supplies transverse torque rod axle brackets (that are not specific to any vehicle or application) as shown below.

Axle Bracket Part Number	Axle Model Number		
48042-000	*Dana (Eaton)	Eaton D460	* It may be necessary to cross- reference the provided axle model number to the current vehicle manufacturer's model number.
		Eaton D480	
46868-000	*Meritor (Rockwell)	Rockwell SL100	
		Rockwell SQ100	
		Rockwell SQHP	



NOTE

Hendrickson recommends heavy-duty and severe-duty TRAAX ROD components for demanding vocational applications.

**TRAAX ROD performance** — Up to \*five times the performance life of conventional double shot bushings and similar performance of ball and socket torque rods, with better energy absorption, delivering superior bushing retention and longer component life for heavy- and severe-duty applications.

- Heavy-duty Recommended for 40,000 lb. to 52,000 lb. capacity suspensions in most vocational applications.
- Severe-duty Recommended for 60,000 Ib. to 70,000 Ib. capacity suspensions. Also available for 40,000 Ib. to 52,000 Ib. capacity suspensions for even longer service intervals.



<sup>6</sup> Based on internal testing of bushing walkout, retention and durability. Actual product performance may vary depending on component and vehicle configuration, operation, service and other factors.

Visit www.traaxrods.com for more benefits and a torque rod conversion calculator to determine length.

Refer any questions on this publication to Hendrickson Tech Services:



Toll-free U.S. and Canada 1.866.755.5968 Outside U.S. and Canada 1.630.910.2800



Parts Identification truckparts@hendrickson-intl.com Technical Support techservices@hendrickson-intl.com



1.630.910.2899



vebsite

Additional Hendrickson Product Information www.hendrickson-intl.com

Actual product performance may vary depending upon vehicle configuration, operation, service and other factors.

All applications must comply with applicable Hendrickson specifications and must be approved by the respective vehicle manufacturer with the vehicle in its original, as-built configuration. Contact Hendrickson for additional details regarding specifications, applications, capacities, and operation, service and maintenance instructions.

TRUCK COMMERCIAL VEHICLE SYSTEMS

1.630.910.2800 (Outside U.S. and Canada)

Call Hendrickson at 1.866.755.5968 (toll-free) or 1.630.910.2800 for additional information.

800 South Frontage Road Woodridge, IL 60517-4904 USA 1.866.755.5968 (Toll-free U.S. and Canada)

Fax 1.630.910.2899

# HENDRICKSON

www.hendrickson-intl.com

59310-004 Rev G 12-20

© 1998 – 2020 Hendrickson USA, LL.C. All Rights Reserved. All trademarks shown are owned by Hendrickson USA, LL.C., or one of the affiliates, in one or more countries Information contained in this literature was accurate at the time of publication. Product chances may have been made after the conviolnt date that are not reflected.